



# **TUCSON** Installation Guide











#### **Required Tools** FLAT HEAD SCREWDRIVERS STARHEAD SCREWDRIVERS MEASURING TAPE **DRILL & BIT** *«111111111* $\ominus$ < 5/16" Diameter




⊕ **€**\_\_\_\_\_

⊒TÈ





## **PRODUCT** INSTALLATION



#### Step 1


Ensure the fixing lug (1) on the vertical bar on the back of the towel warmer.

#### Step 2

Use a tape to measure the distance between the center points of each wall bracket tube; record the distances between points AB, AC, CD, and BD. Mounting point C will determine electrical box location. See Electrical Assembly in following instructions.

#### Step 3


Drill A, B, C, and D holes with an appropriately sized bit.



#### Step 4


Insert the wall screws (2) into plug (3)







Step 5

Install the tube onto the backings.






Step 6






## HARDWIRE INSTALLATION



#### Step 7

#### Without Hardware Kit

Guide the electrical cord through the plastic cap and connect with electrical box.



### Step 8

#### With Hardware Kit

- Create a hole in the wall to let the Hard Wire Leg go through (approx. 2 in. x 3 3/4 in.).

- The leg will be covered by Plate so the hole should be large enough to allow space for electrical connection and leg to go through but not too large so that the plate can cover it fully.

- Guide the electrical cord through the electrical connection mounting tube and use the mounting screw to tighten the electrical connection mounting tube to the vertical bar.

