

AUGUSTA

Towel warmer

Chauffe-serviettes Calentador de toallas



Vernon	Weight (KG)	Tapping Centres (mm)/inch	Fixing Centres (H) (mm)/inch	Distance (D) (mm)/inch	Height (mm)/inch	Length (mm)/inch
AGS-0800500	12.7	462/18.19"	620/24.41"	60/2.36″	800/31.5″	500/19.68″
AGS-1200500	18.9	462/18.19"	1020/40.16″	60/2.36″	1200/47.24″	500/19.68"

Installation:



Step 1: Select the desired mounting position, make sure the wall is adequate to take the fixing points of the rail i.e anchor points must be securely attached to a stud or masonry.

Step 2: Loosely screw the wall support into the wall using the wall screw and washer. Use wall plug if you are fixing into masonry. Do no tighten fully.

Step 3: Manoeuvre the rail back onto the bracket and tighten with the grub screw.

Cleaning:

Do not use any abrasive or chemical cleaners to clean the radiators as this will cause damage to the surface finish. Please use warm water and a damp cloth.
Do not clean when hot.

