



Towel
Warmers

TUCSON Installation Guide




Distributed by Kart ners:











North Vancouver,
British C olumbia, Can ada

Toll: 1.877.490.3537
www.vernontw.com

TUCSON DIAGRAM



Accessories

- | | | | | | | | |
|----------------------------------------------------------------------------------------------|---------------------------|----------------------------------------------------------------------------------------------|----------------------|-----------------------------------------------------------------------------------------------|-----------------------|-------------------------------------------------------------------------------------------------|----------------------------|
| 1  | Solid Fixing Lug
4 pcs | 4  | Backings
4 pcs | 7  | Plate
1 piece | 10  | Wall Plate Screws
2 pcs |
| 2  | Wall Screws
16 pcs | 5  | Set screws
12 pcs | 8  | Plate
1 piece | | |
| 3  | Wall Plugs
16 pcs | 6  | Allen Key
2 pcs | 9  | Set Screws
1 piece | | |

Required Tools

STARHEAD SCREWDRIVERS



FLAT HEAD SCREWDRIVERS




MEASURING TAPE



DRILL & BIT


5/16" Diameter




LEVEL



PENCIL



PRODUCT INSTALLATION




- All the dimensions are shown in millimetres/inch
- Horizontal Tube dia 32mm
- Vertical Tube dia 32mm
- Bracket length – 27mm
- Rated 100,150,300 or 400W dependent on model
- Suitable for 120V supply, three wire connection
- The electric towel rails conform to: the requirements of UL499 CSA C22.2 No.60335-1 and E60335-2-43

Please Note:

- All towel warmers contain a factory – filled glycol mixture
- Not suitable for use on domestic hot water system
- Before staring, ensure situation and orientation


HARDWIRE KIT SPECIFICATIONS



Vernon	Weight (KG)	Tapping Centres (mm)/inch	Fixing Centres (H) (mm)/inch	Distance (D) Height (mm)/inch	Length (mm)/inch
TUS-092060012.7	526/20.71	846/33.31	86/3.38	920/36.22	600/23.62


Step 1

Ensure the fixing lug (1) on the vertical bar on the back of the towel warmer.




Step 2

Use a tape to measure the distance between the center points of each wall bracket tube; record the distances between points AB, AC, CD, and BD. Mounting point C will determine electrical box location. See Electrical Assembly in following instructions.



Step 3

Drill A, B, C, and D holes with an appropriately sized bit.




Step 4

Insert the wall screws (2) into plug (3)





Step 5

Install the tube onto the backings.





Step 6





NOTE:


The power lead must be connected to a socket or connection block, which must be at least 25CM from the floor.



Step 7

Without Hardware Kit

Guide the electrical cord through the plastic cap and connect with electrical box.



Step 8

With Hardware Kit

- Create a hole in the wall to let the Hard Wire Leg go through (approx. 2 in. x 3 3/4 in.).
- The leg will be covered by Plate so the hole should be large enough to allow space for electrical connection and leg to go through but not too large so that the plate can cover it fully.
- Guide the electrical cord through the electrical connection mounting tube and use the mounting screw to tighten the electrical connection mounting tube to the vertical bar.

