



BOSTON Installation Guide




Toll: 1.877.490.3537 www.vernontw.com



BOSTON DIAGRAM




Accessories



Required Tools







Vernon	Weight (KG)	Tapping Centres (mm)/inch	Fixing Centres (H) (mm)/inch	Distance (D) (mm)/inch	Height (mm)/inch	Length (mm)/inch
BOS-0800500	12.7	470/18.5	620/24.41"	60/2.36"	800/31.5"	500/19.68"
BOS-1200600	18.9	570/22.44	1020/40.16"	60/2.36"	1200/47.24"	600/23.62"

Step 1


Use the wall support core (2) to fix the solid fixing lug (1) to the threaded metal pad on the vertical bar on the back of the towel warmer.

Step 2

Step 3

Use a tape to measure the distance between the Drill A, B, C, and D center points of each wall bracket tube; record the holes with an distances between points AB, AC, CD, and BD. appropriately sized bit. Mounting point C will determine electrical box location. See Electrical Assembly in following


instructions.



Step 4


Insert wall screw (3) through wall support (4) then screw into wall plug (7).






Step 5

Install the tube onto the wall support (4)



PRODUCT INSTALLATION


- All towel warmers contain a factory - filled glycol mixture



X	2


Step 6

Add the plastic caps onto the top to cover the screw head and valve.






HARDWIRE INSTALLATION



Step 7

Without Hardware Kit

Guide the electrical cord through the plastic cap and connect with electrical box.



Step 8

With Hardware Kit

- Create a hole in the wall to let the Hard Wire Leg go through (approx. 2 in. x 3 3/4 in.).

- The leg will be covered by Plate so the hole should be large enough to allow space for electrical connection and leg to go through but not too large so that the plate can cover it fully.

- Guide the electrical cord through the electrical connection mounting tube (9) and use the mounting screw (10) to tighten the electrical connection mounting tube to the vertical bar.

